

Cisco Advanced Services Deploy, Maintain, and Troubleshoot Cisco IOS XR Software (DMTXR) 3.6.3

Outline

- Module 1: Configuration Management
- Module 2: AAA Security
- Module 3: Monitoring the Cisco IOS XR Operating System
- Module 4: Monitoring Processes
- Module 5: Interprocess Communication
- Module 6: Network Time Synchronization
- Module 7: Error Messages and Core Dumps
- Module 8: Cisco IOS XR Packet Forwarding
- Module 9: Cisco IOS XR Local Packet Transport Services
- Module 10: Cisco IOS XR Management Plane Protection
- Module 11: Troubleshooting Cisco CRS Traffic Flow
- Module 12: Cisco IOS XR Emergency Recovery
- Module 13: Troubleshooting Cisco XR 12000 Traffic Flow